Toshiba Strata CIX

DP5000-series telephone basics

01 Make a call

Lift the handset, or select Spkr for speakerphone. Dial using your site's outside-line access method when required.

02 Answer a call

Pick up the handset or select Spkr. If the call is not selected automatically, choose the flashing line or extension button first.

03 Announce a transfer

During a conversation, select Cnf/Trn and dial the destination extension. Wait for an answer, introduce the caller, then hang up. To return to the original caller during transfer, select your flashing extension button.

04 Adjust the volume

While listening on the handset, use the volume buttons. For speaker volume, select Spkr and adjust the volume. Your handset volume may return to its default after the call.

Match your phone and system before using this guide. Local programming can change button assignments and available features.

Need help? Visit cts-companies.com/service-requests/.

Original CTS reference, based on Toshiba Strata CIX DP5000-series Telephone Quick Reference Guide (November 2007), printed pages 3, 5-7. Not a manufacturer publication. NEC and Toshiba names identify compatible products.